

Category B & ADI Pt II Safety Questions 01/07/2008				
Question No.	Topic	Show / Tell	Question	Answer
B 01	Oil	Show	Open the bonnet, identify where you would check the engine oil level and tell me how you would check that the engine has sufficient oil.	Identify dipstick / oil level indicator, describe check of oil level against the minimum/maximum markers.
B 02	Steering	Show	Show me / explain how you would check that the power assisted steering is working before starting a journey.	If the steering becomes heavy the system may not be working properly. Before starting a journey two simple checks can be made. Gentle pressure on the steering wheel, maintained while the engine is started, should result in a slight but noticeable movement as the system begins to operate. Alternatively turning the steering wheel just after moving off will give an immediate indication that the power assistance is functioning.
B 03	Coolant	Show	Open the bonnet, identify where you would check the engine coolant level and tell me how you would check that the engine has the correct level.	Identify high/low level markings on header tank where fitted or radiator filler cap, and describe how to top up to correct level.
B 04	H/brake	Show	Show me how you would check the parking brake (handbrake) for excessive wear, make sure you keep safe control of the vehicle	Apply footbrake firmly. Demonstrate by applying parking brake (handbrake) so that when it is fully applied it secures itself, and is not at the end of the working travel.
B 05	Washer fluid	Tell	Identify where the windscreen washer reservoir is and tell me how you would check the windscreen washer level.	Identify reservoir and explain how to check level.
B 06	Horn	Show	Show me how you would check that the horn is working (off road only).	Check is carried out by using control (turn on ignition if necessary).
B 07	Brake fluid	Show	Open the bonnet, identify where the brake fluid reservoir is and tell me how you would check that you have a safe level of hydraulic brake fluid.	Identify reservoir, check level against high/low markings.
B 08	Indicators	Show	Show me how you would check that the direction indicators are working.	Applying the indicators or hazard warning switch and check functioning of all indicators. (may need to switch ignition on, prompt not to start engine)
B 09	Brake lights	Show	Show me how you would check that the brake lights are working on this car. (I can assist you, if you need to switch the ignition on, please don't start the engine)	Operate brake pedal, make use of reflections in windows, garage doors, etc, or ask someone to help. (may need to switch ignition on, prompt not to start engine)
B10	Brakes	Tell	Tell me how you would check that the brakes are working before starting a journey.	Brakes should not feel spongy or slack. Brakes should be tested as you set off. Vehicle should not pull to one side.

Category B & ADI Pt II Safety Questions 01/07/2008				
Question No.	Topic	Show / Tell	Question	Answer
B11	Lights	Tell	Tell me how you would check that the headlights & tail lights are working. (No need to exit vehicle)	Explanation: Operate switch (turn on ignition if necessary), then walk round vehicle. (As this is a "Tell Me" question, there is no need to physically check the lights.)
B12	Tyre pressure	Tell	Tell me where you would find the information for the recommended tyre pressures for this car and how tyre pressures should be checked.	Manufacturer's guide, use a reliable pressure gauge, check and adjust pressures when tyres are cold, don't forget spare tyre, remember to refit valve caps.
B13	Tyres	Tell	Tell me how you would check the tyres to ensure that they have sufficient tread depth and that their general condition is safe to use on the road.	No cuts and bulges, 1.6mm of tread depth across the central ¾ of the breadth of the tyre and around the entire outer circumference.
B14	Windscreen Washers	Show	Show me how you would clean the windscreen using the windscreen washer and wipers.	Operate control to wash and wipe windscreen (turn ignition on if necessary).
B15	Windscreen Demister	Show	Show me how you would set the demister controls to clear all the windows effectively, this should include both front and rear screens.	Set all relevant controls including; fan, temperature, air direction / source and heated screen to clear windscreen and windows. Engine does not have to be started for this demonstration
B16	Rear fog light	Show	Show me how you would switch on the rear fog light(s) and explain when you would use it/them. (No need to exit vehicle, Please don't start the engine.)	Operate switch (turn on dipped headlights and ignition if necessary). Check warning light is on. Explain use.
B17	Headlights	Show	Show me how you switch your headlight from dipped to main beam and explain how you would know the main beam is on whilst inside the car	Operate switch (with ignition or engine on if necessary), check with main beam warning light
B18	Head Restraints	Tell	Tell me how you make sure your head restraint is correctly adjusted so it provides the best protection in the event of a crash	The head restraint should be adjusted so the rigid part of the head restraint is at least as high as the eye or top of the ears, and as close to the back of the head as is comfortable. N.B. Some restraints might not be adjustable
B19	Brakes	Tell	Tell me how you would know if there was a problem with your anti lock braking system	Warning light should illuminate if there is a fault with the anti lock braking system